

Train path requests for cross-border services

Luino factsheet

Valid from 11.12.2016



Help document


- For additional information (principles of mandatory entries in NeTS, special rules for cross-border passenger services and examples), please refer to the factsheet help document:

[Passenger services help document](#)

[Freight services help document/example](#)


Network connection point: Luino

Overview of national and network borders



FFS: km 175.866
 Network border = national border
 RFI: km 65.571

Target status diagram



Operating points to be recorded in AVIS (-NeTS)

To enable all the peripheral systems to function properly at the Luino border, it is essential that the following operating points are recorded, depending on the direction of travel.

Italy → Switzerland Switzerland → Italy				
Operating point	UIC code	Timetable	Purpose of stop	SMS-RU
Luino (LIFS)	83-01113-0	hh:mm	Code(s)	yes

